

Introduction to Spray Painting Techniques

Introduction to Spray Painting Techniques

Designed as a quick-reference guide for beginners and intermediate users.

1. What Is Spray Painting?

- **Definition:** Application of liquid paint (or coating) through a pressurized nozzle that atomizes the material into a fine mist.
- **Common Uses**
 - Automotive refinishing
 - Furniture & cabinetry
 - Artwork & murals
 - Industrial equipment and metal fabrication
 - DIY home projects (walls, fences, decks)

2. Core Components of a Spray System

Component	Function	Typical Options
Paint Supply	Holds the coating (can, bucket, or cartridge).	Aerosol cans, HVLP/airless tanks, gravity-feed cups.
Pressure Source	Generates the airflow that atomizes the paint.	Compressor, turbine, built-in pump (spray guns).
Gun/Nozzle	Shapes the spray pattern and controls droplet size.	Flat fan, round, adjustable fan, air cap size (e.g., 1.0-1.8mm).
Trigger/Control Valve	Regulates flow of paint and air.	Single-action (on/off) or dual-action (air & paint independently).
Filters & Strainers	Remove debris that could clog the nozzle.	Inline mesh filters, cup filters.
Safety Gear	Protects the user and environment.	Respirator, goggles, gloves, coveralls, proper ventilation.

3. Basic Spray Painting Techniques

Introduction to Spray Painting Techniques

3.1. Preparation (The Most Important Step)

1. Surface Cleaning

- Remove dust, grease, rust, and old paint.
- Use detergent, solvent, or a dedicated cleaner; sand if necessary.

2. Surface Repair

- Fill dents, cracks, or holes with appropriate filler; sand smooth.

3. Masking & Taping

- Cover areas you don't want painted with painter's tape, paper, or plastic sheeting.

4. Priming

- Apply a compatible primer to improve adhesion and uniformity.

3.2. Setting Up the Spray Gun

Adjustment	How to Set	Effect
Air Pressure	Start at 20–30?psi for HVLP; 40–70?psi for conventional guns.	Controls atomization; too high ? overspray, too low ? orange peel.
Fluid Flow	Adjust the paint?control knob (or cup) until a steady stream appears without dripping.	Determines coverage rate.
Fan Width	Rotate the air?cap or use a different nozzle.	Wider fan = faster coverage; narrower fan = detail work.
Spray Distance	Hold gun 6–12?in (15–30?cm) from the surface.	Consistent distance yields even thickness.

3.3. Applying the Paint

1. Overlap Technique

- Move the gun in smooth, parallel strokes.
- Overlap each pass by ~30?% of the previous pass to avoid streaks.

2. Consistent Speed

- Keep a steady motion; too slow ? runs, too fast ? thin film.
- Practice on scrap material to gauge the “golden” speed.

3. Multiple Thin Coats

- Apply 2–3 light coats rather than one heavy coat.
- Allow the recommended flash?off or drying time between coats (