

Advanced Solar PV System Design

Advanced Solar PV System Design

Comprehensive, easy-to-read notes for engineers, designers, and students

1. Overview

Aspect	Description
Goal	Maximize energy yield, reliability, and economic return while meeting site-specific constraints.
Scope	Sizing, layout, electrical design, thermal considerations, protection, monitoring, and performance modelling for utility-scale and large commercial PV plants.
Key Drivers	Solar resource, land/roof area, grid interconnection limits, budget, regulatory codes, and long-term operation & maintenance (O&M) strategy.

2. Core Concepts

Concept	Why It Matters	Typical Design Metric
Irradiance & Temperature	Determines the DC power of each module.	Plane-of-Array (POA) irradiance, NOCT temperature.
Module Efficiency & Temperature Coefficient	Affects how much power is produced per unit area and how output changes with temperature.	%/°C (e.g., $-0.35\%/^{\circ}\text{C}$).
Inverter Efficiency Curve	Impacts AC output and overall system LCOE.	% at 25% and 100% load.
System Losses	All non-idealities (soiling, wiring, mismatch, etc.) reduce net yield.	Typical range 10-15% for well-designed plants.
Maximum Power Point Tracking (MPPT)	Ensures modules operate at their optimal voltage/current under varying conditions.	Number of MPPTs per inverter, string-level MPPT.

Advanced Solar PV System Design

Concept	Why It Matters	Typical Design Metric
Voltage Drop & Conductor Sizing	Excessive drop reduces power and can violate code limits.	2-3% voltage drop (typical).
String Configuration & Voltage Limits	Determines how many modules per string and the overall system voltage.	$V_{oc} \leq 0.8 \times V_{DC \text{ bus rating}}$ (temperature-adjusted).
Balance of System (BOS) Components	Include combiner boxes, disconnects, protection devices, monitoring, and grounding.	Selected based on current, voltage, fault level.

3. Design Workflow

1. Site Assessment

- Collect GIS data, topography, shading analysis (3D modeling), and meteorological (TMY) data.
- Identify usable area, orientation, tilt constraints, and access routes.

2. Energy Yield Targeting

- Define annual energy production (kWh) or specific yield (kWh/kW_p).
- Use tools (e.g., PVSyst, SAM, Helioscope) to run baseline simulations.

3. Module & Inverter Selection

- Choose modules based on efficiency, temperature coefficient, warranty, and cost.
- Match inverter DC rating to module string voltage range and desired AC output.

4. String Design & Voltage Check

- Calculate $V_{oc,STC}$ and $V_{oc,low\ temp}$ for each string:

$$V_{oc,low} = V_{oc,STC} \times [1 + \gamma_V \times (T_{low} - 25)]$$